

# ROP-KEY-U

## SPARE KEY FOR ROP-110/111 AND ROP-400/401 (10-PACK)

The **ROP-KEY-U** is designed to be used with the **ROP-110**, **ROP-111**, **ROP-400** and **ROP-401** manual call points. It enables manual testing of their correct operation, as well as resetting the activated manual call points by restoring the pressed plastic pane to its original position.

- designed to work with **ROP-110/EU**, **ROP-111/EU**, **ROP-400/EU**, **ROP-401/EU**
- key enables:
  - testing
  - resetting
- pack contains 10 keys

